

# Sampling, FFT, and the Pre-Lab 1 notebook

Fall 2026 · Prof. Ehsan Roohi

**Lecture and guided Jupyter walkthrough**

# Learning goals

- Explain sample rate, sample interval, record length, and Nyquist frequency
- Run prepared analysis cells in a Jupyter notebook
- Interpret time histories, RMS values, and one-sided FFT spectra
- Recognize aliasing before collecting Lab 1 sound data

# Connection to Lab 1

## PRE-LAB

A known two-tone signal tests sampling and FFT ideas before the laboratory.

The code provides a controlled result that you can predict.

## LABORATORY

The Moku:Go records real microphone signals.

You will compare waveforms, spectra, and replayed sound at several sample rates.

# Jupyter notebook structure

## MARKDOWN CELLS

Instructions, equations, and response areas.

Double-click to edit. Use Shift+Enter to render and move forward.

## CODE CELLS

Python commands that define variables, calculate results, and make figures.

Run from top to bottom with Shift+Enter.

## Opening and saving the notebook

- Download the .ipynb file from Canvas or the course website
- Open it in JupyterLab, Jupyter Notebook, or Google Colab
- Save a personal copy before editing
- Keep code outputs and figures in the submitted file

## Execution order matters

```
A = 1.20  
print(A)  
  
# A later cell can use A only after this cell runs.  
rms_component = A / np.sqrt(2)  
print(rms_component)
```

A restart clears stored variables. Run All rebuilds the notebook state from the first cell.



## The new two-tone signal

```
A1, f1, phi1_deg = 1.20, 18.0, 25.0
A2, f2, phi2_deg = 0.45, 42.0, -15.0

def signal(t):
    return (A1*np.sin(2*np.pi*f1*t + np.deg2rad(phi1_deg))
            + A2*np.cos(2*np.pi*f2*t + np.deg2rad(phi2_deg)))
```

The function returns voltage values for any array of time values.

# Meaning of the Python syntax

## ARRAY OPERATIONS

`np.pi` supplies  $\pi$ .

`np.sin` and `np.cos` accept arrays.

`np.deg2rad` converts degrees to radians.

## FUNCTION OUTPUT

`signal(t)` adds the two components at every requested time.

Changing `t` changes the sampling grid, not the physical signal definition.



# Mean and RMS

## MEAN

The average signed voltage over the record.

Each tone has zero mean over complete cycles.

## RMS

A measure related to signal energy.

For distinct tones over complete cycles:

$$\text{RMS} = \sqrt{(A_1^2 + A_2^2)/2} = 0.9062 \text{ V}$$

# Samples and the underlying waveform

## DENSE REFERENCE

The gray curve in the notebook uses 20,001 calculated time points. It shows the mathematical signal clearly.

## 48 HZ SAMPLES

The blue markers contain only 10 measured values in the first 0.20 s. Lines between markers do not add information.

## Sample rate, interval, and record length

```
fs = 126.0                # samples per second
dt = 1/fs                 # seconds between samples
duration = 1.00           # seconds
n = int(round(duration*fs))
t = np.arange(n)/fs

print(dt, n, t[-1])
```

Students read these settings and analyze the resulting data. They do not modify the code.

## Nyquist frequency

- The Nyquist frequency equals  $f_s/2$
- A sampled record can represent frequencies only from 0 to  $f_s/2$
- The 42 Hz tone requires  $f_s$  greater than 84 Hz
- Rates of 336 and 126 Hz meet this condition. Rates of 72 and 48 Hz do not

## Aliasing changes the measured frequency

**FS = 126 HZ**

Nyquist frequency: 63 Hz

Observed FFT peaks: 18 and 42 Hz

Both components remain below Nyquist.

**FS = 48 HZ**

Nyquist frequency: 24 Hz

Observed FFT peaks: 18 and 6 Hz

42 Hz appears at  $|42 - 48| = 6$  Hz.

## The prepared sampling analysis

```
for fs in sample_rates:
    n = int(round(duration*fs))
    t = np.arange(n)/fs
    x = signal(t)
    records[fs] = (t, x)
    sample_mean, sample_rms = mean_and_rms(x)
    print(fs, sample_mean, sample_rms)
```

Students transfer the printed values to an analysis table and calculate RMS percent error.



## Reading the time-domain figures

- Compare sample markers with the dense reference over the same time window
- Look for too few points per cycle and apparent changes in shape
- Read the printed mean and RMS values
- Avoid judging sample quality from smooth connecting lines

## The prepared FFT analysis

```
X = np.fft.rfft(x*window)
magnitude = np.abs(X)/(n*coherent_gain)
magnitude[1:-1] *= 2
frequency = np.fft.rfftfreq(n, d=1/fs)

# Read the dominant frequencies from the output.
# Compare them with predictions made before execution.
```

Students interpret the FFT output. They do not write or complete these lines.



## Expected FFT peaks

### ADEQUATE SAMPLE RATE

336 Hz gives peaks at 18 and 42 Hz.

126 Hz gives peaks at 18 and 42 Hz.

### ALIASING

72 Hz gives peaks at 18 and 30 Hz.

48 Hz gives peaks at 18 and 6 Hz.

# Guided notebook walkthrough

- 1 Define the signal
- 2 Choose  $f_s$  and create sample times
- 3 Plot samples beside the reference
- 4 Compute the one-sided FFT
- 5 Explain the physical meaning

## Required data analysis

- Calculate theoretical mean and RMS, then compute RMS percent errors
- Predict every FFT peak before viewing the spectra
- Compare predicted and observed peaks and explain aliasing
- Choose a sample rate and duration for a new measurement and justify both

# Common notebook problems

## CODE PROBLEMS

NameError: run earlier cells.

Missing figure: run the plotting cell.

Changed variable: restart and Run All.

## ANALYSIS PROBLEMS

Wrong units for phase.

Confusing  $f_s$  with signal frequency.

Calling a smooth line measured data.

Reporting peaks without explaining aliasing.

## From the notebook to Moku:Go

- Choose a sample rate from the known or estimated sound frequency
- Record at least one second and save the data as a MAT file
- Plot the measured waveform and compute its spectrum
- Compare the dominant peak with the tuning-fork frequency and replay the recording

# Pre-Lab 1 submission

## BEFORE SUBMITTING

Run All cells.

Keep figures visible.

Complete four response sections.

Export to HTML or PDF if Canvas requests it.

## DEADLINE

Normally posted Monday before the laboratory.

Submit before your own section begins.

Late pre-labs are not accepted.